


EZPull Trap Voice Release Quick Reference



The image shows a blue handheld device with a microphone at the top and several buttons on the front. The buttons include a target icon, a speaker icon, a power icon, and a play/pause icon. Two LEDs are located at the top of the device. Arrows point from text boxes to these LEDs and buttons.

Left LED
Blinks once a sec. - unit is On and waiting for a voice command.
Steady light when voice is detected.

Right LED
Blinks once every 4 sec. - unit is asleep. Press & release the Power key to wake up.

Manual Target
Press & release to throws a bird.
Left light will come on steady for 1 Sec.

Voice Sensitivity
Press & release. Left Light Blinks.
Number of blinks indicating the Sensitivity level from 1 (very low) to 5 (very high)

Pause & Play
To pause, press & hold, both lights flash alternately, when they stop, release the key then left light will flash rapidly.
To Play press & hold again, both lights flash alternately and when they stop release the key.

Power
To turn ON, press & release, both lights will come on. Left light will flash.
To turn OFF, press & hold, until Right light blinks rapidly, release key when light stops blinking.

Communication problem with the base station
Both lights blink twice when a bird is called for.