

EZPull MTX-8 Quick Guide

Manual Mode

1. If the display is blank, press the ON/OFF key [⏻] to turn ON.
2. For Manual release, press the [1] key.
3. Singles: press and release any key 1-8.
4. True pair: Press the Fire [🎯] key. Select the two traps using keys 1-8. When the shooter is ready, press the Fire [🎯] key again to release.
5. Rafael pair: Press the Fire [🎯] key. Select the same trap twice. When the shooter is ready, press the Fire [🎯] key again to release. The second target will follow in approximately 2.4 seconds.
6. Exit manual mode by pressing the [⏻] key.

Voice Release Mode

(available only on model MTX-8VR)

1. If the display is blank, press the ON/OFF key [⏻] to turn ON.
2. For Manual/Voice release, press the [1] key.
3. Singles: press and release any key 1-8. When the Red light starts blinking, call "Pull" to release. If "Pull" is not picked up within 16 seconds, the selection is cancelled.
4. True Pair: Press the Fire [🎯] key. Select two traps using keys 1-8. When the Red light starts blinking, call "Pull" to release.
5. Rafael pair: Press the Fire [🎯] key. Select the same trap twice. When the Red light starts blinking, call "Pull" to release. The second target will follow in approximately 2.4 seconds.
6. Report pair: Select the first trap and immediately press the Fire [🎯] key. Select the second trap. When the Red light starts blinking, call "Pull" to release. Your first gunshot will release the second target. If gunshot is not picked up within 6 seconds, the unit reverts to the previous state and you can call "pull" again without pressing any keys.
7. To "lock" the selected target(s) for repeatedly releasing on each "pull": When the Red LED started blinking slowly, press and hold any of red colored keys. Keep holding the key for approximately 1 second. Release the key as soon a pad-lock icon appears on the lower left corner of the display and the Red LED glows. The target(s) selected will repeat on each "Pull". You have approximately 5 seconds to reload after you shoot. Press any key to cancel.
8. Exit manual mode by pressing the [⏻] key.

Automatic Mode

1. If the display is blank, press the ON/OFF key [⏻] to turn ON.
2. For Auto release, press the [2] key.
3. Use the [3] and/or [8] keys to select the number of shooters then press the Fire [🎯] key to accept.
4. Press the Fire [🎯] key again to start. After a couple of seconds the display will show the first target.
5. To release targets, simply press Fire [🎯] key. The system automatically advances to the next shooter.
6. Report on gunshot: If the menu is set for Report on gunshot, the Red light will stay on after you release the first target. When you hear the gunshot, press the Fire [🎯] key again to release the second target and advance to the next shooter.
7. To go back and repeat the same target(s), press the [4] key.
8. To skip targets, press the [5] key.
9. To momentarily switch to a fully manual mode, press the [3] key. The MTX-8 will operate in manual mode. Press the [⏻] key to return to automatic sequence mode at the last segment where you left it.
10. Exit automatic mode by pressing the [⏻] key.

