

EZPull TX4S Quick Guide

Super-Sporting

When the TX4S is set to Super Sporting mode:

1. Singles: Press any target key: 1-A, 2-B, 3-C or 4-D.
2. Two keys true pair: Pressing any two target keys simultaneously throws a true pair.
3. True pair Using TP key:
 - 3.1. Press the center key (TP). Both T1 and T2 lights are flashing indicating no targets selected.
 - 3.2. Select the first trap using target keys 1-4. The T1 light glows steady. The T2 still flashing indicating you need to select a second trap.
 - 3.3. Select the second trap. Both lights will glow steady indicating the pair is ready for release. If you do not select both traps within 6 seconds, the pair request will timeout
 - 3.4. To change the pair selection, simply press another target key. The newly selected trap will replace the first trap selected.
 - 3.5. To select a Rafael pair, select the same trap twice. The second target will follow in the delay set in the EZPull Trap receiver (Typically 2.4 seconds.)
 - 3.6. When the shooter calls "pull", press the TP key again to release the pair.
 - 3.7. To abort pair selection, press any two keys simultaneously.
 - 3.8. Once both traps are selected, you have one minute (60 seconds) to throw the targets. After one minute, the pair requests will timeout.
4. True pair lock: It is possible to lock the True Pair selection so the same pair can be released repeatedly by pressing only the TP key.
 - 4.1. Press and hold the center key (TP) until the center light turns on (about 1.5 Seconds). Release the TP key. Both T1 and T2 lights are flashing indicating no targets selected.
 - 4.2. Select the first trap using target keys 1-4. The T1 light glows steady. The T2 still flashing indicating you need to select a second trap.
 - 4.3. Select the second trap. Both lights will glow steady indicating the pair is ready for release. If you do not select both traps within 6 seconds, the pair request will timeout
 - 4.4. To change the pair selection, simply press another target key. The newly selected trap will replace the first trap selected.

- 4.5. To select a Rafael pair, select the same trap twice. The second target will follow in the delay set in the EZPull Trap receiver (Typically 2.4 seconds.)
- 4.6. When the shooter calls "pull", press the TP key again to release the first pair.
- 4.7. After the first pair, the center light will blink indicating locked pair mode. To release the pair again, press the TP key.
- 4.8. To abort locked pair mode, press any of target keys 1-4.
- 4.9. Locked pair mode will timeout if you do not release another pair within 90 seconds.

Standard Sporting Clays

When the TX4S is set to Standard Sporting mode:

1. Singles: Press target key 1-A or 2-B.
2. True pair 1 + 2: Press the center key (TP).



TX4S_Pro

TX4S

EZPull TX4S Quick Guide

Delayed Pair with Solo Delay on TX4S

When set to solo delay, the TX4S can throw a delayed pair to simulate a report pair:

1. Press any target key: 1-A, 2-B, 3-C or 4-D for the first target. The T1 light glows steady and the center light blinks.
2. Immediately press any target key 1-A, 2-B, 3-C or 4-D for the second target. The T2 light flashes rapidly.
3. For a Rafael pair, press the same key twice.
4. The first target will launch 3 seconds after pressing the first key. The second target will follow after the delay selected in the settings (see TX4S Setup Manual).

Delayed Pair with Solo Delay on TX4S_Pro

When using TX4S_Pro for TargetManager card system, a solo shooter can throw a delayed pair to simulate a report pair:

1. Use a card with Solo Delay or if TargetManager is in Sporting Clays with delay mode, press keys [2], [3] or [4] for a respective delay in seconds.
2. Press any target key: 1-A, 2-B, 3-C or 4-D for the first target and immediately press any target key 1-A, 2-B, 3-C or 4-D for the second target.
3. For a Rafael pair, press the same key twice.
4. The first target will launch after the solo delay period.
5. The second target will launch after another solo delay period.