

EZPull Personal Trap Voice Release

Left LED

Voice release: blinks once a sec. - unit is waiting for a voice command.
Steady light when voice is detected.

Manual Target

Press & release to throws a bird.
Left light will turn on steady for 1 Sec.

Wobble Trap Control

Use only with a wobble receiver.
When pressed, both lights are flashing. To continuously wobble, keep holding until both lights are off and release the key.
To stop the wobble and "inch" to desired direction, press and release as soon as lights start flashing.



Right LED

Mute: blinks once a sec.

Voice Mute/Unmute

Press & release. If voice release is active, the right light flashes and the unit becomes muted.
If the unit is muted, the left light flashes and voice release becomes active.

Power

To turn ON, press & release, both lights will turn on.
To turn OFF, press & hold, both lights will alternate. Release key only after both lights are off.