

# EZPull Trap Voice Release

## Model TVR-WP145 Quick Reference

**Manual Target**  
Press & release to throws a bird.  
Top light will come on steady for 1 Sec.

**Power**  
To turn ON, press & release, both lights will come on.  
To turn OFF, press & hold, the lower light blinks rapidly, release key when light stops blinking.

**Pause & Play**  
To pause, press & hold, both lights flash alternately, when they stop, release the key then top light will flash rapidly.  
To play, press & hold again, both lights flash alternately. Release the key when the lights stop flashing



**Microphone Screen**  
Avoid touching the screen

**Top LED**  
Blinks once a sec. - unit is On and waiting for a voice command.  
Steady light when voice is detected.

**Bottom LED**  
Blinks once every 4 sec. - unit is asleep. Press & release the Power key to wake up.

Communication problem with the base station  
Both lights blink twice when a bird is called for.